cecotec

BOLERO COOLMARKET TT 90 WHITE E
BOLERO COOLMARKET TT 90 INOX E
BOLERO COOLMARKET TT 90 BLACK E
Frigorífico 1 Puerta / 1 Door Fridge



bolero

Manual de instrucciones
Instruction manual
Manuel d'instructions
Bedienungsanleitung
Manuale di istruzioni
Manual de instruções
Handleiding
Instrukcja obsługi
Návod k použití
Kullanma kılavuzu

1. PARTS AND COMPONENTS

Fig. 1

1. Freezer compartment
2. Temperature knob
3. Upper shelf
4. Lower shelf
5. Crisper drawer
6. Door shelves

NOTE
The graphics in this manual are schematic representations and may not exactly match the appliance.

2. BEFORE USE

- This appliance includes a safety package to protect it during transport. Unpack the appliance and keep the original packaging and materials in a safe place. It will help prevent any damage if the appliance needs to be transported in the future. In case the original packaging is disposed of, make sure all packaging materials are recycled accordingly.
- Make sure all parts and components are included and in good conditions. If there is any piece missing or in bad conditions, contact the official Cecotec Technical Support Service immediately.
- During transport, hold the base and lift the refrigerator carefully at an angle of less than 45 degrees. Do not place the appliance upside down or horizontally. Place the refrigerator on its base by means of the adjustable feet.

Box content:
- Refrigerator
- Ice cube tray
- Ice scraper
- Instruction manual

3. INSTALLATION

- Place the appliance on a flat and solid surface. You should not place it on any soft material.
- Select a location in which there are no heat sources nearby. Keep the refrigerator away from direct sunlight and other heat-producing appliances.
- Select a dry, well-ventilated location where corrosive air is not present.

- To improve the refrigeration system efficiency and save energy, you must ensure good ventilation around the appliance to reduce heat. To do so, there must be enough empty space around the refrigerator.
- It is recommended to ensure a minimum of 100 mm clearance from the back of the refrigerator to the wall, a minimum of 100 mm on the top of the refrigerator, a minimum of 100 mm from the side of the refrigerator to the wall, and to leave enough space for the doors to open 135° as shown in Figure 2.

Preparation

1. Clean the refrigerator parts with warm water and a soft cloth or with neutral detergent and clean water, and then dry them.
2. Place the temperature knob in position 3 and connect the appliance to the electric circuit.
3. The refrigerator compressor will light up.
4. Close the door and wait for 30 minutes. If the freezer compartment temperature has clearly decreased, this indicates that the refrigeration system is working properly.
5. When the refrigerator is in operation for a certain period of time, the temperature controller will automatically adjust the temperature if you do not open the door too often.
6. If you follow the above steps correctly, your refrigerator is ready for use.

Note: the refrigerator electrical parts must only be cleaned with a dry cloth.

Refrigerator door

This refrigerator has been designed with the door hinges on the right-hand side. If you wish to change the opening direction, follow these instructions.

Warning

Unplug the appliance from the power supply before reversing the opening direction of the door. Remove the plug from the socket before starting.

Fig. 3

1. Upper hinge cover
2. Upper hinge fixing screws
3. Top hinge
4. Adjustable feet
5. Bottom hinge
6. Lower hinge fixing screws
7. Adjustable feet
8. Door

1. Remove the upper hinge cover (1) and loosen the upper hinge fixing screws (2). Remove the upper hinge (3).

2. Place the refrigerator on the floor for better support.
3. Remove the door feet (4 and 7) and loosen the lower hinge fixing screws (6). Next, remove the lower hinge (5).
4. Change the lower hinge (5) position to the opposite side of the appliance. Position and support the door on the lower hinge (5), place the screws (6) again and the adjustable feet (4 and 7), align the door and place the upper hinge (3) with the help of the screws (2).
5. Place the upper hinge cover (1).

4. OPERATION

Temperature knob

- The temperature of the refrigerator compartment and the freezer compartment can be adjusted via the temperature knob on the right side of the freezer compartment.
- Turn the temperature knob to control the refrigerator inner temperature. The marks on the knob do not match the temperature degrees, so the temperature can be set from 0 to 5.
- The first level activates a forced stop of the refrigeration and level 5 corresponds to the lowest refrigeration temperature.
- If you turn the knob from position 1 to 5, the temperature will decrease steadily.
- Place the temperature knob in position 2 or 3 for normal operation.

Food storage

This appliance features the accessories illustrated in figure 1. Find useful tips on food storage here below. You can remove the shelves and the crisper drawer if necessary.

Please note

Do not allow food to touch the appliance surface directly.

Storing food in the freezer compartment

This compartment helps preserve frozen perishable food for a longer period of time.
To get better results, follow these tips:

- Store fresh and high-quality food.
- Make sure food is wrapped or correctly covered before storing it. This will prevent food from dehydrating, discolouring, or losing flavour and will help maintain its freshness. It will also prevent odour transfer.
- Allow hot food to cool down before placing it in this compartment.

Dairy products and eggs

- Most pre-packed dairy products have a best-before date. Store them and use them within the best-before date.
- Butter can be easily contaminated by strong odours, so it is best to keep it in a sealed container.

Red meat
- Place fresh red meat in a dish and cover it without pressing it with wax paper, plastic, or aluminium foil.
- Store raw and cooked meat in different dishes. This will prevent liquids from transferring from raw meat and contaminating cooked meat.

Poultry
- You must rinse fresh whole poultry inside and outside under cold running water, dry it, and place it on a plate. Cover them without pressing with plastic or aluminium foil.
- You must also store poultry meat this way. Stuff whole poultry right before cooking it. Otherwise, it can lead to food poisoning.

Fish and seafood
- You must consume whole fish and fillets on the day of purchase. Until then, store them in the refrigerator covered without pressing with plastic, wax paper, or aluminium foil.
- If you wish to store food at night or for a longer period of time, try to select really fresh fish. You must rinse whole fish with cold water to remove scales and dirt, and then dry it with paper towels. Place whole fish or fillets in an airtight plastic bag.
- Keep seafood refrigerated at all times. Consume it within 1-2 days.

Convenience food and leftovers
- You can store this food in an appropriate and covered container, so food does not dry.
- Conserve it only for 1-2 days.

Crisper drawer
- The crisper drawer is ideal location for fresh fruits and vegetables.
- Be careful not to store this food at temperatures below 7 °C for long periods of time.
- There may be undesired changes at low temperature, like softening, browning or accelerated decomposition.
- Do not store avocados (until ripe), bananas or mangoes.

Food	**Location**
Cream cheese	Door top shelf
Eggs	Door shelf
Fruits and vegetables	Crisper drawer
Meat, sausages, cheese, milk	Low area (lower shelf/drawer cover)
Dairy products, canned food, cans	Top door shelf
Drinks and bottles	Door shelf

5. CLEANING AND MAINTENANCE

- You must clean the refrigerator at least once a month. Before cleaning it, you must unplug it from the power supply.
- Clean the interior and the exterior of the appliance with a soft and slightly damp cloth.
- If it is too dirty, use a soft cloth with neutral detergent and remove moist with a dry cloth.
- Remember to clean the defrosting drain, located on the rear part, right above the glass cover.

If you wish to keep the refrigerator off for a long period of time, follow these steps:

1. Unplug the refrigerator from the power supply.
2. Remove the food.
3. Clean and dry the interior of the refrigerator.
4. Leave the door open to prevent unpleasant odours while the refrigerator is not used.

Defrost

- If the refrigerator runs for a long time, frost will appear on the interior surface of the freezer compartment. This could increase the energy consumption and decrease the refrigeration capacity. For that reason, you must clean the freezer compartment at least once a month.
- When doing so, turn off the power, open the door, and move the food to a cold place. Use a plastic spatula to remove the frost. Next, remove the frost and clean the interior of the freezer compartment with a dry and soft cloth.

Note:
Do not use metallic tools to clean the freezer compartment, as they could damage it.

6. TROUBLESHOOTING

If your appliance is experiencing problems other than those described below, please contact the Customer Service of the shop where you purchased it or the official Cecotec Technical Support Service.

Problem	Cause	Solution
The appliance does not work	There is no power supply.	Make sure the outlet works properly with other appliances or check if the appliance is connected to the power supply.
	The fuse has blown.	Replace the fuse.

The appliance makes a lot of noise	It is too close to a wall, the surface is not stable, or the accessories in the refrigerator are not placed correctly.	Secure the base of the refrigerator by adjusting the feet, moving the appliance away from the wall or positioning the interior accessories correctly.
The appliance does not refrigerate enough	The door is open too often or was open for a long period of time.	Close the door and do not open it too often
	The refrigerator is too close to the wall.	Move the appliance away from the wall to ensure good ventilation.
	The refrigerator is full.	Remove the food from inside the appliance.
	The temperature is not set correctly.	Turn the temperature knob to position 3 or higher.
There are odours in the appliance	Some food inside the appliance has expired and/ or is in bad condition.	Dispose of the expired food and wrap the other food.
	You must clean the interior of the appliance.	Clean the interior of the refrigerator.

The following problems are not faults

- You hear the noise of the cooling fluid flowing through the pipes: this is normal.
- Moisture on the outer surface of the appliance during humid seasons does not constitute a problem; simply wipe the collected moisture with a soft, dry cloth.
- The compressor and the condenser may have become hot during periods of strong heat.
- The door frame is a little warm; this means that the condenser is working to remove moisture from the air.

7. TECHNICAL SPECIFICATIONS

You can find more information on this model by scanning the QR code on the energy label.

Reference	00126	00127	00128
Model	Bolero CoolMarket TT 90 White E	Bolero CoolMarket TT 90 Inox E	Bolero CoolMarket TT 90 Black E
QR code			
Voltage	220 - 240 V		
Rated frequency	50 Hz		
Rated current	0.7 A		
Climate class	ST/N (*)		
Capacity	91 l		
Refrigerant	R600a (21 g)		
Rated power consumption	85 kWh/year		
Gas	C_5H_{10}		

(*) Refrigerating appliance intended for use at room temperatures between 16 °C and 38 °C.

Technical specifications may change without prior notification to improve product quality.
Made in China | Designed in Spain

8. DISPOSAL OF OLD ELECTRICAL AND ELECTRONIC APPLIANCES



This symbol indicates that, according to the applicable regulations, the product and/or batteries must be disposed of separately from household waste. When this product reaches the end of its shelf life, you should dispose of the batteries/accumulators and take them to a collection point designated by the local authorities.
Consumers must contact their local authorities or retailer for information concerning the correct disposal of old appliances and/or their batteries.

Compliance with the above guidelines will help protecting the environment.

9. TECHNICAL SUPPORT AND WARRANTY

Cecotec shall be liable to the end user or consumer for any lack of conformity that exists at the time of delivery of the product under the terms, conditions, and deadlines established by the applicable regulations.
It is recommended that repairs be carried out by qualified personnel.
If at any moment you detect any problem with your product or have any doubt, do not hesitate to contact the official Cecotec Technical Support Service at +34 96 321 07 28.

10. COPYRIGHT

The intellectual property rights over the texts in this manual belong to CECOTEC INNOVACIONES, S.L. All rights reserved. The contents of this publication may not, in whole or in part, be reproduced, stored in a retrieval system, transmitted, or distributed by any means (electronic, mechanical, photocopying, recording or similar) without the prior authorization of CECOTEC INNOVACIONES, S.L.