cecotec

ROCK'NTOAST 3IN1



Manual de instrucciones
Instruction manual
Manuel d'instructions
Bedienungsanleitung
Manuale di istruzioni
Manual de instruções
Handleiding
Instrukcja obsługi
Návod k použití

1. PARTS AND COMPONENTS

Fig. 1.
1. Stainless steel cover
2. Power light indicator (Red)
3. Ready light indicator (Green)
4. Top housing
5. Lock
6. Lower housing
7. Plates release tab
8. Non-stick plates

2. BEFORE USE

Take the product out of the box.
Remove all packaging materials. Keep the original box.
Make sure all the components are included and in good conditions, otherwise, contact immediately the official Technical Support Service of Cecotec.
Clean the cooking plates with a sponge and soapy water.
Use a dry cloth or paper towel to thoroughly dry the plates before assembling them.

Note: You may notice a slight burning smell or smoke when using the sandwich maker for the first time, caused by the excess of lubricants from the manufacturing process. This does not affect the safety of your appliance.

3. OPERATION

Warning: Do not use this product to defrost frozen food. All food must be completely defrosted before cooking it in this product.
The cooking plates and metal surfaces of the unit will become extremely hot during use. Wear heat-proof mitts or gloves and touch only the handle.

Cooking plates
The 3-in-1 sandwich maker includes 3 different interchangeable plates:
Sandwich plates
Waffle plates
Grill plates

To remove and replace the plates:
Open the device.
Slide the plates release button and remove the plates.
Select the desired plate, clip it into position and carefully press it down until it clicks into position.

Warning: Always allow the device to cool down before assembling or disassembling the plates.

Getting the 3-in-1 sandwich maker ready
Pour a teaspoon of vegetable oil onto the non-stick plates.
Use a paper towel to spread oil on the plates and then wipe off any excess.
Plug the device into a power socket. The red operation light indicator will turn on. The ready green light indicator will remain off while the appliance preheats.
Close the appliance during the preheating process. As it preheats, prepare the sandwich, waffle or ingredients to be cooked.
After approximately 5 minutes, the ready green light indicator will turn on, indicating the appliance is ready for use.

Using the sandwich maker
Pour or place the ingredients to be cooked directly on the lower non-stick plate.
Close the device and use the lock to fasten the handles. Do not open it during the cooking process.
The green ready light indicator may turn on and off due to automatic temperature control.
Note: During the cooking process, the upper part of the device may slightly bulge.
Food will be ready in approximately 4-5 minutes. You may cook food for longer according to your likings.
Once food is ready, open the lid and remove it using a plastic or wooden spatula.
Warning; Do not use metal knives or objects, as this may cause damage to the non-stick plates.

Tips
When using precooked sandwiches or waffles, make sure they fit in the non-stock plates or cut them in such way that they do.
Use only butter or ordinary margarine when preparing precooked sandwiches or waffles, as synthetic or low-fat spreads tend to overheat at lower temperatures and form dark brown deposits which could stick to the non-stick plates.
Precooked sandwiches and waffles must be buttered on the outside, unlike conventional ones.

Use heat-proof gloves and utensils when using this device.

4. CLEANING AND MAINTENANCE

Unplug the sandwich maker and allow it to cool down before cleaning. The unit is easier to clean when it is slightly warm.
Do not immerse in water or any other liquid, nor wash it in dishwashers.
Wipe the cooking plates with a soft cloth to remove food residue. If any foodstuff has stuck to the cooking plates, pour a bit of warm water mixed with detergent over the food residue and clean the plates with a non-abrasive scouring pad.
Do not use abrasive materials that could scratch or damage the non-stick coating.
The plates are dishwasher safe.
Wipe the outside of the sandwich maker with a damp cloth only. Do not clean the outside with any abrasive scouring pad, as this will damage the finish. Keep the product in a cool, dry place.
The power cord can be wound around the base of the product for its storage.
You can use the lock to keep the plates together, in order to store the product in an upright position.

5. TECHNICAL SPECIFICATIONS

Product reference: 03057
Product: Rock'nToast 3in1
700-800 W, 220-240 V~, 50/60 Hz.
IPX4

6. DISPOSAL OF OLD ELECTRICAL APPLIANCES



The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), specifies that old household electrical appliances must not be disposed of with the normal unsorted municipal waste. Old appliances must be collected separately, in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.
The crossed out "wheeled bin" symbol on the product reminds you of your obligation to dispose of the appliance correctly. If the product has a built-in battery or uses batteries, they should be removed from the appliance and disposed of appropriately.
Consumers must contact their local authorities or retailer for information concerning the correct disposal of old appliances and/or their batteries.

7. TECHNICAL SUPPORT SERVICE AND WARRANTY

This product is under warranty for 2 years from the date of purchase, as long as the proof of purchase is submitted, the product is in perfect physical condition, and it has been given proper use, as explained in this instruction manual.
The warranty will not cover the following situations:
The product has been used for purposes other than those intended for it, misused, beaten, exposed to moisture, immersed in liquid or corrosive substances, as well as any other fault attributable to the customer.
The product has been disassembled, modified, or repaired by persons, not authorised by the official Technical Support Service of Cecotec.
Faults deriving from the normal wear and tear of its parts, due to use.
The warranty service covers every manufacturing defects of your appliance for 2 years, based on current legislation, except consumable parts. In the event of misuse, the warranty will not apply.

If at any moment you detect any problem with your product or have any doubt, do not hesitate to contact Cecotec Technical Support Service at +34 963 210 728.